

HYDRAULIC BRAKE

Connect the Mityvac Brake Bleeder No. 6860 or equivalent to the bleed valve.

NOTE:

- Check the fluid level often while bleeding the brakes to prevent air from being pumped into the system.
- When using a brake bleeding tool, follow the manufacturer's operating instructions.

Pump the brake bleeder and loosen the bleed valve. Add fluid when the fluid level in the reservoir is low.

If air enters the bleeder from around the bleed valve threads, seal the threads with teflon tape.

Repeat the above procedures until no air bubbles appear in the plastic hose.

If the brake bleeder is not available, perform the following procedure.

Pump up the system pressure with the lever until there are not air bubbles in the fluid flowing out of the reservoir small hole and lever (pedal) resistance is felt.

1. Pump the brake lever or pedal several times, then squeeze the brake lever or pedal all the way and loosen the bleed valve 1/2 turn. Wait several seconds and close the bleed valve.

Do not release the brake lever or pedal until the bleed valve has been closed.

2. Release the brake lever or pedal slowly and wait several seconds after it reaches the end of its travel.

3. Repeat the steps 1–2 until there are no air bubbles in the bleed hose.

After bleeding air completely, tighten the bleed valves to the specified torque.

TORQUE: 6 N·m (0.6 kgf·m , 4.3 lbf·ft)

FRONT:

Fill the master cylinder reservoir with DOT 4 brake fluid from a sealed container to the top of the casting ledge.

REAR:

Fill the reservoir to the upper level line with DOT 4 brake fluid from a sealed container.

