



- 7 Select a target device name, and then press the **ENT** switch.



- 8 When the pairing is complete, device name is displayed.

Rider	When pairing rider headset
Passenger	When pairing passenger headset



- 9 Return to the riding information, previous screen or Home screen. **▶P.38**  
 You can also perform the above settings by using the touch screen.

**To disconnect the headset: ▶P.162**