

Maintenance Schedule

Items	Frequency	Whichever Comes First		Initial Maint.	Regular Maint. Interval				Refer to page:
		⇒			mi	600	1,200	1,800	
		Note	Month	km	1,000	2,000	3,000	4,000	
* Fuel Line						I		I	–
* Throttle Operation						I		I	73
Air Cleaner	Note 1			C	C	C	C	C	68
Crankcase Breather				I	I	I	I	I	72
Spark Plug				I	I	I	I	I	79
* Valve Clearance				I	I	I	I	I	–
Engine Oil				R	R	R	R	R	62
** Engine Oil Strainer Screen						C		C	–
** Engine Oil Centrifugal Filter						C		C	–
** Engine Idle Speed				I	I	I	I	I	78

* Should be serviced by your dealer, unless the owner has the proper tools and service data and is mechanically qualified. Refer to the official Honda Service Manual (page 162).

** In the interest of safety, we recommend these items be serviced only by your dealer.