

Overheating	89
Oxygenated Fuels	115

P

Parking	11
Parts Location	18
PGM-FI (Programmed Fuel Injection)	
Malfunction Indicator Lamp (MIL)	24, 90
Protective Apparel	9

R

Rear Brake Lock	30
Recommended	
Coolant	59
Fuel	37
Oil	58
Refueling	37
Removal	
Battery	65
Battery Lid	66
Center Cover	67
Clip	68
Maintenance Cover	69
Repair Kit	92

Reporting Safety Defects	120
Riding	35
Riding Precautions	10

S

Safety Labels	7
Safety Precautions	9
Seat	39
Shutter	29
Spark Plug	70
Specifications	121
Speedometer	20
Start Button	26
Starting the Engine	31
Steering Lock	28
Stopping Engine	27, 102
Storage	
Center Compartment	40
Equipment	39
Fairing Pocket	42
Owner's Manual	41
Storing Your Vehicle	106
Switches	26