

REQUISITE SERVICE

- Fuel tank removal (page 2-4)
- Air cleaner case removal (page 6-3)
- Carburetor removal (page 6-4)
- California Model Only: AVCV and PCV tubes removal from carburetors

PROCEDURE		Q'ty	REMARKS
Separate No. 3/No. 4 carb. from No. 1/No. 2 carb..			
(1)	Bystarter arm shaft	1	
(2)	Spring	1	
(3)	Bystarter arm	3	
(4)	Choke cable holder	1	
(5)	Rear bracket	1	
(6)	Front bracket	1	
(7)	No. 3 carb. synchronization spring	1	
(8)	Air joint pipe (3-way)/O-ring	1/2	
(9)	Fuel joint pipe (3-way)/O-ring	1/2	
Separate No. 3 carb. from No. 4 carb..			
(10)	No. 4 carb. synchronization spring	1	
(11)	Thrust spring	1	
(12)	Air joint pipe (rubber)	1	
(13)	Air vent pipe/O-ring	1/2	
(14)	Fuel joint pipe (2-way)/O-ring	1/2	
Separate No. 1 carb. from No. 2 carb..			
(15)	AVCV and PCV as an assembly	1	California Model Only
(16)	No. 1 carb. synchronization spring	1	
(17)	Thrust spring	1	
(18)	Air joint pipe (rubber)	1	
(19)	Air vent pipe/O-ring	1/2	
(20)	Fuel joint pipe (2-way)/O-ring	1/2	