

TOOLS

Spoke wrench, 5.8 × 6.1 mm	07701-0020300	2 required
Pin spanner	07702-0020001	
Bearing remover weight	07741-0010201	
Attachment, 32 × 35 mm	07746-0010100	
Attachment, 37 × 40 mm	07746-0010200	
Attachment, 42 × 47 mm	07746-0010300	
Attachment, 24 × 26 mm	07746-0010700	
Attachment, 22 × 24 mm	07746-0010800	
Pilot, 15 mm	07746-0040300	
Pilot, 17 mm	07746-0040400	
Pilot, 20 mm	07746-0040500	
Pilot, 25 mm	07746-0040600	
Bearing remover shaft	07746-0050100	
Bearing remover head, 20 mm	07746-0050600	
Driver	07749-0010000	
Bearing remover assembly	07936-KC10500	
Bearing remover collets	07936-MK50100	
Attachment, 28 × 30 mm	07946-1870100	
Driver	07949-3710001	
Slider guide attachment	07974-KA50102	
Lock nut wrench	07KMA-KAB0100	
Slider guide, 16 mm	07PMG-KZ40100	
Lock nut wrench, 20 mm	07VMA-MBB0100	

TROUBLESHOOTING

SOFT SUSPENSION

- Weak shock absorber spring
- Incorrect suspension adjustment
- Oil leakage from damper unit
- Tire pressure too low

HARD SUSPENSION

- Damaged shock absorber mounting bearing
- Bent damper rod
- Damaged swingarm pivot
- Bent swingarm pivot
- Incorrect suspension adjustment
- Tire pressure too high

STEERS TO ONE SIDE OR DOES NOT TRACK STRAIGHT

- Bent rear axle
- Axle alignment/chain adjustment not equal on both sides

REAR WHEEL WOBBLING

- Bent rim
- Worn rear wheel bearings
- Faulty tire
- Tire pressure too low
- Faulty swingarm pivot bearings
- Loose or bent/broken spokes